

CHARGER REMOTE CONTROL AND DISPLAY OPTIONS

Two options are available for remotely controlling battery chargers and displaying charging information. Both options are compatible with the following charger and control products:

High Frequency Chargers	Eclipse II
	Eclipse II Plus
	Eclipse II – 2 circuit
	Eclipse II Extreme
SCR Chargers	Ultra Maxx
	Ultra Charge
	PowerStar Plus
	PowerStar (SCR2000 control only)
Ferroresonant Chargers	Accu-Charger (AC2000 control only)
	Battery-Mate series (AC2000 control only)

Remote Stop Switch – Option 103A

Pressing this large momentary mushroom style switch shuts down the charger and disables the output. The charger then displays “Manual Stop.” Mounting flanges make the switch easy to locate on any nearby rack, post or wall. This option includes 20 ft. of thin, flexible cable that connects the low voltage signal (5V) back to the charger control.



UC2000 Remote Display – Option 102

The remote display module provides remote access to charger “Manual Stop” and “Equalize” controls. It also includes indicators for “Charge complete”, “80% Charged”, “Equalize”, “Fault” and a 6 element bar graph to indicate charger output current levels. Mounting flanges make the switch easy to locate on any nearby rack, post, or wall. This option includes 20 ft. of thin, flexible cable that connects the low voltage signal (5V) back to the charger control.

